

Design Build As-Built Plans Process

Once construction is complete and all changes have been recorded on the “As-Built” plans, the plan set is to be submitted directly to the Office of Design Policy & Support and will be processed as follows.

Innovative Delivery	<ol style="list-style-type: none">1. Place the plans in the <i>CST\Construction Plans\As Built Plans</i> folder in ProjectWise setting the Document Type as follows. Document Group: <i>Preliminary Engineering</i> Document Category: <i>Design Plans</i> Document Type: <i>As Built Plans</i>2. Set the Public Access for all plans in the <i>CST\Construction Plans\As Built Plans</i> folder.<ol style="list-style-type: none">a. Select all the files in the folder.b. Right-click and select Modify.c. Select the GDOT Environment tab.d. Scroll down to Public Access and enter 1 for the value.e. Click on Apply and then Close.3. Set the Sheet Types for all sheets under the <i>CST\Construction Plans\As Built Plans</i> folder.<ol style="list-style-type: none">a. Select all the same type files in the folderb. Right-click and select Modifyc. Select the GDOT Environment tab.d. Scroll down to Sheet Type and select the appropriate sheet type from the drop-down.e. Click on Apply and then Close.f. Continue until all sheet types are assigned to the plans.4. Send an email to the Engineering Document Management staff (EDMDocs@dot.ga.gov) to notify them of the new project.
---------------------	--

EDM STAFF	<ol style="list-style-type: none"> 5. Set Final Status on the files in the <i>CST\Construction Plans\As Built Plans</i> folder. <ol style="list-style-type: none"> a. Select all files. b. Right-click and select Change State=>Set Final Status c. Click OK 6. Create a Document Set in the <i>Record Plan Set</i> folder. <ol style="list-style-type: none"> a. Navigate to the <i>PI\Record Plan Sets\ 15 - As Built Plans</i> folder. b. In the folder, right-click and select Set=>New. c. In the <i>Create Document Set</i> dialog, enter <i>As Built Plans</i> for the Name, leave the Description field blank, and click on OK. d. Navigate back to the <i>CST\Construction Plans\As Built Plans</i> folder and select all files in the folder. e. Drag the files into the Document Set dialog box that should still be open. f. Close the Document Set dialog box.
-----------	---